
數位訊號處理實驗 Digital Signal Processing Laboratory Lab 4 Heart Rate Estimation

Task 1

Detect the R wave from your recorded ECG signals.


Pre-Processing of ECG Signals to Locate R Peaks (3/3)



Sample Points

Task 3

- Implement the pre-processing of the ECG signals(Lab 3) and R-peak detection in real time and display the processed ECG signals (i.e., noise-reduced ECG signals) and the R-peaks in real time.
 - Better modularize your signal processing flow. That is, please make each block as a function and then perform function calls.
 - Note that you can implement your signal processing modules in PC or in Arduino.
 - Can you display "Heart Rate" (Inverse of the RR interval) in real time?
 - Can you "beep" for each R peak
 - The evaluation will depend on the average of the elapsed time for 100 loops of your signal processing and display (see ShortIntro2MatlabProfiler.pdf)



Notes on Real Time Implementation: Time Profiling of Each Step

- Sampling rate for data acquisition (Arduino side)
- Data transfer rate (Arduino to PC)
- FIFO handling
- Pre-processing: notch filtering (filter order), high pass filtering (filter order), squaring and flattening (LPF order), thresholding
- Peak finding
- Display


(See ShortIntro2MatlabProfiler.pdf, DisplayWithCorrectTiming.mov and DisplayWithIncorrectTiming.mov)


Task 2

Find the R-peaks in MIT-BIH database.

(You have to take care "group delay" introduced by your linear phase FIR filtering in order to obtain the almost the same R-peak time as provided by the MIT-BIH database)

- Detailed description about the provided data, please see the Lab 4 on the LMS e-learning system.
- Please draw a table in your report. The first column is the name of the data set, the 2nd column is TP, the 3rd column is FN, and the 4th column is FP.
- Please justify how you estimate your TP, FN, and FP and the precision when matching your results with the ground truth.





```
>> x = [123454321];
>> h = [ 1 2 3 2 1];
>> y = conv(x,h);
>> y_same = conv(x,h,'same');
>> figure
>> subplot(2,1,1)
>> stem([0:(length(x)+length(h)-1)-1], y);
>> subplot(2,1,2)
>> stem([0:length(x)-1], y_same);
>> axis([0 12 0 40])
>> title('y')
                                    20
>> title('remove group delay')
                                    10
                                                               6
                                                                       8
                                                                               10
                                                                                        12
                                                        remove group delay
                                    40
                                    30
                                    20
                                    10\oplus
                                                                               10
                                     0
                                                      4
                                                               6
                                                                       8
                                                                                       12
```